



FLEXcon's Warranty & Limited Remedy Policy for Graphic Advertising for Floors, Indoor Carpets & Outdoor Walkways

This warranty is made in lieu of any and all other express or implied warranties, including any implied warranty of merchantability. FLEXcon warrants that its Systems for Graphic Advertising for Floors, Indoor Carpets & Outdoor Walkways, constructed using only FLEXcon overlamine films, marking films, and produced and installed in accordance with FLEXcon's written instructions, will for a period of six (6) months (floors and indoor carpets) or of three (3) months (outdoor walkways) after application (i) maintain quality excepting ordinary and expected wear and tear; and (ii) will adhere to FLEXcon's recommended surfaces and be removable without damage to the surface. FLEXcon will replace or refund the price of such quantity of FLEXcon Graphic Advertising for Floors, Indoor Carpets & Outdoor Walkways films found not to meet this warranty.

The warranty is exclusive. In no case shall FLEXcon be liable for any other direct or indirect damages or loss, including without limitation any incidental, special, or consequential damages, or any labor charges incident to the removal or replacement of Graphic Advertising for Floors, Indoor Carpets, or Outdoor Walkways. This warranty and limited remedy does not limit or exclude any claims for personal injury allegedly caused by the negligence of FLEXcon Co. Inc.

Graphic Advertising for Floors

Application Instructions

FLEXcon's System for Graphic Advertising for Floors is designed to be applied to smooth surfaces including: waxed and non-waxed commercial PVC tile, certain ceramic tile, and sealed concrete.

FLOOR CONDITION:

Floor surface must be clean prior to application of graphics. Traditional floor cleaning methods can be used to prepare the surface. Insure that the floor surface is adequately dry before application of graphics.

APPLICATION METHOD:

1. Peel the backing paper (release liner) 1" down from the top. Fold, and crease the backing paper.
2. Align and apply the graphic starting at the top using firm strokes with a plastic squeegee, stiff cardboard, or a soft cloth. Continue removing the backing paper and smooth out the squeegee. Re-squeegee the edges of the graphic using firm strokes to insure edge adhesion.

ROUTINE MAINTENANCE:

1. Do not clean or wax graphics for at least 24 hours after application.
2. When selecting a floor wax, insure it meets or exceeds ASTM D 2047 standards for appropriate static coefficient of friction (.5 min)
3. Avoid damaging graphics by heavy equipment traffic (fork trucks, pallets, or other heavy equipment).

NOTE: To avoid risk of injury, immediately remove graphics if any edge of the graphic lifts, and replace with a new graphic.

REMOVAL INSTRUCTIONS:

- Lift one edge of the graphic and pull, using short quick strokes. Pull at an angle less than 45 degrees for best results.



Graphic Advertising for Indoor Carpets

Application Instructions

FLEXcon's System for Graphic Advertising for Indoor Carpets is designed to be applied to low-pile commercial-grade, stain-resistant or non-stain resistant carpets only.

CARPET CONDITION:

Carpet surface must be free of lint and debris prior to application of graphics. A thorough vacuuming is recommended. If recently shampooed or steam cleaned, make sure that the carpet surface is completely dry before application of graphics. [NOTE: FLEXcon's System for Graphic Advertising for Indoor Carpets can be applied at a temperature as low as 55°F (13°C).]

APPLICATION METHOD:

1. Peel the backing paper (release liner) 1" down from the top. Fold, and crease the backing paper.
2. Align and apply the graphic starting at the top using firm strokes with a plastic squeegee, stiff cardboard, or a soft cloth. Continue removing the backing paper and smooth out the squeegee. Re-squeegee the edges of the graphic using firm strokes to insure edge adhesion.

ROUTINE MAINTENANCE:

1. Do not clean or vacuum over graphics for at least 24 hours after application.
2. Warm water/mild soap (dish detergent) and sponge can be used to periodically clean top surface of graphic.

NOTE: To avoid risk of injury, immediately remove graphics if any edge of the graphic lifts, and replace with a new graphic.

REMOVAL INSTRUCTIONS:

1. Lift one edge of the graphic and pull, using short quick strokes. Pull at an angle less than 45 degrees for best results.

NOTE: Not all low-pile carpets are manufactured identically. Graphics may not have the same adherence properties on some low-pile **plush** carpets as on other commercial grade low-pile carpets. Please test all carpet surfaces prior to final application of graphic to be sure adhesive removes cleanly.



Graphic Advertising for Outdoor Walkways

Application Instructions

FLEXcon's System for Graphic Advertising for Outdoor Walkways is designed to be applied to slightly textured asphalt and well cured concrete outdoor walkway surfaces. It is not designed for roadways involving automobile traffic.

OUTDOOR WALKWAY CONDITION:

Outdoor walkway surface must be clean prior to application of graphics. A rigid/rough bristle broom can be used to clean away sand/loose debris. Warm water with a hand scrub brush should then be used to clean remaining surface debris. Make sure that the outdoor walkway surface is adequately dry before the application of graphics. (NOTE: FLEXcon's System for Graphic Advertising for Outdoor Walkways is designed to be applied at a minimum temperature of 50°F (10°C). It is not designed for cold weather installations.)

APPLICATION METHOD:

1. Peel the backing paper (release liner) 1" down from the top. Fold, and crease the backing paper.
2. Align and apply the graphic starting at the top using firm strokes with a plastic squeegee. Continue removing the backing paper and smooth out with the squeegee. Re-squeegee the edges of the graphic using firm strokes to insure edge adhesion.

ROUTINE MAINTENANCE:

1. Warm water/mild soap (dish detergent) and sponge can be used to periodically clean top surface of graphic.
2. Avoid damaging graphics with heavy equipment traffic (fork trucks, pallets, or other heavy equipment).

NOTE: To avoid risk of injury, immediately remove graphics if any edge of the graphic lifts, and replace with a new graphic.

REMOVAL INSTRUCTIONS:

1. Lift one edge of the graphic (using a putty knife) and pull, using short quick strokes. Pull at an angle less than 45 degrees for best results.
2. Based on application surface condition, some adhesive residue may be experienced. Warm water with dish detergent and a rigid bristle brush should be used to clean residue.