

Photo Tex™

Installing suggestions – Floor Use – EXS (UP) - (High Tack)!

Must be applied to clean floors and in good even/level condition for best results.

Recommended use: (Indoor), personnel that has experience with signage installs.

Placements: Tile, Ceramic, Smooth/Polish Concrete, Marble, Epoxy

INSTALLING:

Rinse application area with warm clean water and a dab of dawn soap (if needed) and allow to dry prior to application.

The floor finish must be firmly attached to subfloor. Floor finishes that do not adhere well to subfloor may separate/release resulting in premature lifting of the graphic and/or cause damage to the floor during removal.

Test before applying to uneven tile as this may result in scuffing Image or poor adhesion.

Peel & Stick: Larger graphics Approx. (36" & up) We suggest not to take the entire liner off at one time. Instead, peel back the liner approximately halfway. Make sure you crease the liner, so it does not flip back into position. Simply apply the exposed adhesive area to your chosen location. Reposition until your set in the place desired. Once your lined up, then continue to slowly pull the backer/loner downward in 4-8" increments, smoothing the Photo Tex with a squeegee or firm hands (on smaller decals). On larger width (36" & Up) please use a squeegee and start from the center out. Do not be afraid to press the material into the floor.

If any air pockets are seen, first try pressing them down by using a circle motion. If that does not work, then you will need to lift the material in that area slowly and re-apply.

If multiple panels are used, butt all edges for floor use. Do not overlap seams.

Maintenance Photo Tex S-UP may be cleaned and maintained using normal commercial procedures. In order to maintain the longevity of the decal, please keep in mind the following... Graphics are not designed to be driven over with motorized vehicles like cars, trucks, tow motors, or other heavy machinery. We do suggest the graphic provider to test the substrate for suitability.

If any edge of the decal lifts from the floor, the entire decal must be immediately removed and replaced to prevent a tripping hazard. Avoid the use of heavy equipment or dragging heavy items across floor graphic. Clean and re-wax that area.

The determination of suitability of this product for any specific use is solely the responsibility of the user. No representations guarantee or warranties of any kind are made to the accuracy of suitability for specific specification.